



# Inline & Endline SprinkGUARD™

## Installation Instructions

### Step 1

It is recommended that you consult a fire suppression installation company regarding the draining of the suppression lines before installation.

### Step 2

Remove any packaging from the SprinkGUARD.

### Step 3

Carefully lift the SprinkGUARD above the suppression line and sprinkler head.

**NOTE:** Make sure the SprinkGUARD is centered over the sprinkler head.

### Step 4

Carefully lower the SprinkGUARD down over the sprinkler head until the legs rest on the suppression line.

**NOTE:** Be sure to center the sprinkler head in the middle of the base plate hole.

**NOTE:** If installing the Drop SprinkGUARD, slide the SprinkGUARD down the line until the base plate hole is in contact with the female fitting. Then you can allow the legs to rest on the suppression line.

### Step 5

Place the first U-bolt on the suppression line from the underneath side of the SprinkGUARD.

**NOTE:** Make sure the U-bolt lines up with the holes cut in the base plate.

### Step 6

Start the nylon-threaded lock nut with your fingers and then tighten with the appropriate wrench or ratchet and socket.

### Step 7

Repeat steps 4 & 5 to complete the installation.

**NOTE:** Never let go of the SprinkGUARD while installing. Dropping the SprinkGUARD could result in serious damage or physical injury.

**Approved for use with the following sprinkler heads:**

**Reliable Model:** RA1314, RA1325, RA1414, RA1425, R2921, R1712, R1722, R3612, R3622

**Viking Model:** VK300, VK350, VK100, VK102, VK200, VK202

**Tyco Model:** TY313, TY3121, TY4131, TY315, TY325, TY3211, TY3111, TY4111, TY4211

