



Sidewall SprinkGUARD™

Installation Instructions

Step 1

It is recommended that you consult a fire suppression installation company regarding the draining of the suppression lines before installation.

Step 2

Remove any packaging from the SprinkGUARD.

Step 3

Locate the Sprinkler head to be protected.

Step 4

Carefully place the SprinkGUARD over the center of the sprinkler head.

Step 5

Mark the four anchor holes in the base plate on the wall for drilling.

Step 6

Carefully remove the SprinkGUARD from the sprinkler head.

Step 7

Locate the marks made on the wall in order to drill for the anchors.

Step 8

Install the anchor of your choice as per manufacturer instructions.

Step 9

Once you have the anchors secured in the wall, carefully place the SprinkGUARD onto the anchors. To complete securing the SprinkGUARD by following the instructions provided by the manufacturer of the anchor.